

5259 Easy Set-Up Guide

Choose your settings

- 1) Go to advanced settings-
 - Turn stat off, pressing bottom right hand corner
 - Press On/Off button and Book button at the same time, hold for 1 sec, till **1ADJ** is showing in the bottom of the circle
- 2) Press Book button to go to 2nd setting, **2 SEN**. Use the arrows to toggle through the settings. **iN** is the internal sensor (ambient), **OUr** is the external sensor (floor).
- 3) Press Book button 5 times till it shows **6PrG** – choose here the number of days you want programmed the same. Choose between 5 days, 6 days or 7 days. Use the arrow keys to select the number required.
- 4) Turn thermostat off and then back on again, using the On/Off button, to get back to the home screen

Set up Time and Date

- 1) Hold down on the **Clock** symbol till the screen changes.
- 2) Use the arrows to select the correct seconds
- 3) Press the **Clock** symbol
- 4) Use the arrows to select the correct hour
- 5) Press the **Clock** symbol
- 6) Use the arrows to select the correct day number (1=Monday, 7=Sunday)
- 7) Press the **Clock** symbol to get back to the home screen.

Start programming

- 1) Hold down on the **Book** button for 6/7 seconds till the screen changes.
- 2) Event 1 (wake up) – use the arrows to set the time you would like your floor to start heating
- 3) Press the **Book** button
- 4) Use arrows to set the temperature you would like your floor to heat up to.
- 5) Press the **Book** button
- 6) Event 2 (leave the house) – use the arrows to set the time you would like your floor to stop heating
- 7) Press the **Book** button
- 8) Use arrows to set the “Eco Temperature” (or the temperature you set when you don’t want the floor to be heating up. We recommend around 6° less than the temperature you set when you are wanting the floor warm.
- 9) Press the **Book** button
- 10) Repeat steps 2-9 for events 3 and 4 (if you don’t want the floor to heat in the middle of the day, set both times at the eco temperature)
- 11) Repeat steps 2-9 for events 5 and 6 (if you don’t want the floor to heat in the evening, set both times at the Eco Temperature)
- 12) If you have set your thermostat to programme 5 days the same or 6 days the same, you now need to repeat steps 2-9 for the week end days (these only have 2 events, 1 time for the floor to start heating and 1 for the floor to stop heating)
- 13) Turn Thermostat off and on again to get back to the home screen,

A typical set up, where you are only wanting the floor to heat twice a day, would look something like:

06.00	24°
08.00	16°
11.30	16°
12.30	16°
18.00	24°
20.00	16°

This would mean that between 6am and 8am, the floor would be at 24°. Through the day the floor would only start to heat up if the temperature dropped below 16°, and then it would only heat it back up to 16°. At 6pm, the floor would start to warm up again, until 8pm when it will drop back down to the 16°, until 6am the next day.

Manual Mode

- 1) If you don't want the thermostat to run to a programme, change to the **Manual** mode by pressing on the **Book** button, when on the home screen. You will see the symbol above the number in the middle of the screen change between a **Clock** and a **Hand**. The **Hand** shows you are in **Manual** mode, the **Clock** shows you are in **Programme** mode.
- 2) When in Manual mode, you can use the arrows to select the temperature you would like your floor to be. This is the figure below the line. The figure above the line shows the temperature your sensor is recording.

Congratulations, you have now set up your thermostat and can now leave this running.